

Auto Speed - The cruise control for irrigation

Automatic Speed adjustment via remote control on the hose reel



To use Auto Speed, you need an SMS or Internet control on the hose drum that allows you to set the speed.

Follow this guide to set up the control system

What do I have to do

- Set the irrigation amount in mm.
- The retraction speed is calculated and transmitted to the machine based on the nozzle diameter, the pressure and the working width.


Manual adjustment of the irrigation quantity


(without remote control on the hose reel)

In the Raindancer app, you can specify the desired irrigation amount in millimetres. Once irrigation begins and pressure is applied, the app displays the necessary retraction speed in meters per hour.

Here's how to use it:

Select the drum icon and navigate to Auto Speed.

 Here, you can input the desired millimetres. This value will remain until you decide to change it.

 Once pressure is applied, the app will indicate the appropriate speed to achieve this millimetre dosage in the plan values.

Please note that any subsequent changes in pressure are not automatically adjusted for; to manage this, a remote control for your reel is required.

Revision #10

Created 1 March 2024 15:14:19 by Jens Götze

Updated 30 April 2024 17:25:05 by Jens Götze