


# Before irrigation - Checklist

Before each irrigation, it is necessary to prepare the sector control to ensure trouble-free operation from the start.

A connection to the Raindancer is usually only made every 7 minutes!  
The correction of the stops is therefore not done immediately.

## Checklist

- Release the Clutch.
- Make sure that the arrows on the stops of the sector control point in the direction of the switch lever
- The switch lever must not be engaged.
- Please ensure that the switch lever is stable enough not to jump over the stops.
- Adjust the left and right stops so that they do not water too close to the field boundaries
- Engage the Clutch.
- After a few minutes, the stops automatically adjust to the field edges



## Special case for guns with reverse switch levers.

The procedure is mostly identical. The direction of the stops is also in the direction of the switch lever. Make sure that the gun does not irrigate beyond the field borders in this setup as well.

Revision #5

Created 4 March 2024 14:34:39 by Jens Götze

Updated 30 April 2024 17:23:49 by Jens Götze