

Units - Metric or Imperial

Changing the units in the Raindancer system is centralised and affects all outputs in the entire system.

You can find the settings for this under **Master Data** → **Units**

At the top you will find the switch between a predefined metric set of units or an imperial set of units.

Conversion between the metric and imperial systems can lead to unusual rounding and decimal values.

Under the simple switching between the systems you will find the individual unit categories used in the Raindancer system.

To change individual units, uncheck **Use default** and then select your preferred unit from the selection box.

Click on **Save** and your system will now show you the selected unit in the selected category.

Revision #3

Created 12 March 2024 16:06:19 by Jens Götze

Updated 26 April 2024 14:57:54 by Jens Götze