

Initial start-up of the M2M router

Optionally, the Raindancer Beacon comes with a preconfigured, ready-to-use M2M Router (M2M – »Machine to Machine Communication«), prepared to be mounted to DIN Rails.

Overview


Front Panel	Rear Panel
	
<ul style="list-style-type: none">1 Hollow Pin / Terminal Block Port Power Supply2, 3, 4 LAN Ethernet Ports5 WAN Ethernet Port6 Status LED Power Supply7, 8, 9 Status LED LAN Ports10 Status LED WAN Port	<ul style="list-style-type: none">1 GSM Main Antenna Connector2 Wi-Fi Antenna Connector3 GSM Aux. Antenna Connector4 Reset Button5 Status LED GSM

Setup

1. Attach GSM Antenna to Connector [1] on the router's rear panel.
Note: when lacking imprints, usually the GSM Antenna is the »thicker« one.

2. Attach Wi-Fi Antenna to Connector [2] on the router's rear panel.

Note: by default, the preconfigured routers come with Wi-Fi deactivated, when not ordered with an alternative configuration, attaching the Wi-Fi Antenna is not required.



3. Connect the Raindancer Beacon(s) via Ethernet cable to one of the ports [2], [3] or [4] on the router's front panel.

Note: Do not connect the Beacon(s) to the WAN Ethernet Port [5]!

4. Connect the power Adapter to the rocket on the router's front panel [1].

Pay attention to polarity, when connecting to an alternative power source (9W/9VDC min, 12V rec., 18V/30V max, depending on router model type)!

Revision #3

Created 7 March 2024 14:33:48 by Jens Götze

Updated 30 April 2024 11:11:22 by Jens Götze