

Ocmis API

image.png and or type unknown

This guide applies to all IP controllers in the OCMIS product family running software version **24.0.1 or later**:

Irtec Smart Rain, OCMIS RainControl 5 & Marani

1. Create a New API in the Raindancer Portal

1. Configure the API connection in Raindancer under **Settings → API → New API**

Edit API

API Credentials	
API-Type	Ocmis Irrigation API
API Name	OCMIS-API
Information	In the Ocmis web portal the values that are entered here have to be stored in the "personal data" of the "account" menu. Ensure that in the Ocmis web portal for the devices to be controlled the Raindancer panel-serialnumber is stored in the "configuration" of the "settings" menu.
Id	MjYtMDYtMzA6YWEwZjk2MjQtNzU5NC00Y2NmLWlwNmEtZTZhNGY0Mjc5NDEx The ID is pregenerated and will be fixed with saving the data.
Key	 Create an individually password as key.
Activated	<input checked="" type="checkbox"/>


2. **API Name:** Freely selectable
Example: OCMIS API
3. **ID:** Automatically generated
4. **Key:** Freely selectable
Example: Raindancer2026!

2. Configure the API and Irrigator in the OCMIS Portal

Enter the Raindancer API credentials in the OCMIS Portal.

1. Log in to the OCMIS Portal (<https://www.irrivero.com/>)
2. Navigate to **"My Apps"** and click **"Digital Irrigation"**
image.png
3. Click **"Account"**
image.png

4. Click **"Edit Personal Data"**




5. Enter the **API ID** and **API Key**, then click **Save**







Token ELCOS	
ID Raindancer	MjYtMDYtMjU6N2QzYmRiMTctODI1Ni00NTgzLWFIMTctOGM4NDMxC
Key Raindancer	Raindancer2026!


Configure the Irrigator in the OCMIS Portal


1. Open the **Irrigator Overview**.
2. Navigate to **Settings → Configurations**.
3. Select **Raindancer Mode** and enter the serial number of the **Raindancer module** installed on the irrigator cart for this machine.
4. **Save**

Systems - Overview Edit data

VIR [] (E200503) 

Name	VIR [] 640
Tipology	
GMT (H)	(GMT+02:00) Europe/Rome
Map zoom	10
Hourly cost €/h	0
Annual maintenance cost €	0
Assigned pump	Select pump to be assigned ▼
Probe link	
Gun assigned	Raindancer ▼
Gun serial number	36_19_0133_14 [] 5


 save

3. Assign the OCMIS Controller Serial Number in the Raindancer Portal

1 Find the Controller Serial Number

1. Log in to the **OCMIS Portal**

2. Copy the irrigator's serial number **without the parentheses**



2 Assign the Controller to an Irrigator

1. Log in to the **Raindancer Portal**.
2. Open the **Setup and Controller** section.
3. **Controller Type:** OCMIS API
4. **API Name:** The API name created in **Section 1.2** (Example: OCMIS API)
5. **Select Controller:** Choose the copied serial number from **Section 3.1** (Example: **OCE200503**)

General		Setup and Controls	
Setup Method ?	Pulling the Gun Carriage (Default) <small>When regularly altering between setup methods, configuring "Pulling the Hose Reel" is recommended.</small>		
Control Type ?	Ocmis (Cloud-API) v	API Name ?	OCMIS-API
		Controller ?	OCE200503 <small>Device Id of API (e.g. Serial No.)</small>

4. Set up the OCMIS control unit on the reel

For the following steps, it is necessary to familiarize yourself with the reel's user manual to avoid making incorrect settings. The manual also contains the access credentials for the various configuration menus of the OCMIS control unit.

It must also be ensured that the modem of the OCMIS control unit is active and that either a dedicated SIM card or the e-SIM of the installed router is working.


If you have any questions regarding the topics in this section, please contact your OCMIS sales partner!

Activate Raindancer mode for the irrigator trolley


1. First, enter the password **ABC123** via the lock icon at the bottom left

  or type unknown


2. Now use the green arrow keys to scroll to the gun configuration, then use the rotary dial to switch to Raindancer mode

 or type unknown

3. On the main page, click the cloud icon with the gear symbol

 or type unknown

4. Click the "DIGITAL" button to switch to the Raindancer dependency mode

 or type unknown

Revision #10

Created 17 June 2024 14:26:54 by Jens Götze

Updated 1 July 2026 13:47:47 by Tobias Scheps